



TE Throttle: Changing Control Board Instructions

1.) Unscrew all Six Screws to Remove Cover



2.) Remove Connector from board Use a pair of needle nose pliers to loosen nuts and to squeeze tabs to off the board



- 3.) Seat new board, screw on the nuts and plug in the connector 4.)
Close cover and secure all six screws.
5.) Your TE Throttle board has been updated.